Ryobi ONE+ RY18CS20A-0 18V Chainsaw 20cm No Battery

Model: 5133005414

Manufacturer: RYOBI

EAN: 4892210199515

Product Code: 469121

R3,321

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950