

PDP Afterglow Wave Gamepad Nintendo Switch Nintendo Switch OLED D-Pad Home button



Model: 500-238-WH

Manufacturer: PDP

Product Code: 1086892

R1,562