



Canon AD-E1 Flash adapter



Model: 4943C001

Manufacturer: CANON

EAN: 4549292184549

Product Code: 1343639

R2,695

Multi-Function Shoe Adapter AD-E1

For a seamless transition from your current hot shoe accessories to the multi-function shoe, the Multi-Function Shoe Adapter AD-E1 is the answer. The Multi-Function Shoe Adapter AD-E1 provides a reliable connection for dust and drip proof Speedlite accessories that you may already own such as the Speedlite EL-1, Speedlite 600EX II-RT, Speedlite 600EX-RT, Speedlite 580EX II, ST-E3-RT or OC-E3 flash cord. The shoe adapter will also hold current accessories such as shotgun mics and on-camera LED panels securely to the camera body with dual locking pins on the multi-function shoe side.