

Bissell Deep reach cleaning tool for carpet and upholstery cleaning



Model: 2367

Manufacturer: BISSELL

EAN: 011120244632

Product Code: 1402630

R1,130

This tool can be attached to your BISSELL carpet cleaner's, or spot cleaner, hose for more functionality.

Set the tool directly on top of the stain you would like to remove, and pull the trigger to spray a mixed solution of formula and water onto that stain. It will remove the stain in 3 easy steps: the extra-long rubber needles shoot formula into the bottom of carpets and rugs to target the root of the stain, then you should gently scrub the brushes to help break up dirt and debris and let the suction action lift the stain away.