

Bosch 2 607 010 629 jigsaw/scroll saw/reciprocating saw blade



Model: 2607010629

Manufacturer: BOSCH

EAN: 3165140579353

Product Code: 1444138

R904

- T 119 BO Basic for Wood
- T 119 B Basic for Wood
- T 111 C Basic for Wood

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.

itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950