

# **Bosch 2 608 135 021 power jigsaw accessory**



Model: 2608135021

Manufacturer: BOSCH

EAN: 3165140030557

Product Code: 1485679

## **R3,277**

Saw blade guide for saw blade 2 607 018 011.