



ESGE ESG 7020 Whisk disc



Model: 7020

Manufacturer: ESGE

EAN: 4011689107115

Product Code: 1500862

R1,003

The whisk disc is the gentle specialist for everything thick and creamy.

You can use it to stir light batters for pancakes, omelettes and egg batters. You can stir puddings until creamy and emulsify salad sauces and dressings - even cosmetic creams. You can create mayonnaise, remoulade or herb butter in seconds (and without artificial additives!). And you can mix your cocktails and drinks like a professional bartender. Despite all the stirring sustainability, the whisk disc is gentle on the ingredients that should not be chopped up - for example raisins in a batter.