

Bosch Jigsaw blade T 301 CD



Model: 2608637590

Manufacturer: BOSCH

EAN: 3165140016308

Product Code: 1501526

R852

- T 301 CD
- HCS, ground teeth and taper ground
- Softwood, chipboards, wood core plywood, fibre boards (10-65 mm)