

Bosch Pad Holder Black



Model: 1600A023KX

Manufacturer: BOSCH

EAN: 4053423227321

Product Code: 1540051

R950

Choose the right pad and start cleaning. From everyday cleaning to heavy-duty use, all pads are designed for different materials and surfaces. Thanks to its hook-and-loop fastening, the selected pad can be attached on the pad holder in just a few seconds. Use the kitchen pad for pots, pans, and kitchen surfaces, while the heavy-duty pad handles baking trays, uncoated cooking utensils, or ovens. The non-scratch pad is designed to gently clean pots, pans, sinks, hobs, and kitchen appliances. Sustainably constructed as it is dishwasher-safe up to 50°C and reusable.