Caso Eierkocher, fr bis zu 3 Eier, Ein-/Ausschalter (2774)

Model: 2774

Manufacturer: CASO

EAN: 4038437027747

Product Code: 1542294

R1,428

Caso Eierkocher, für bis zu 3 Eier, Ein-/Ausschalter (2774)

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950