

Bosch 2 608 837 710 circular saw blade 19 cm 1 pc(s)



Model: 2608837710

Manufacturer: BOSCH

EAN: 3165140958509

Product Code: 1549687

R1,365

Standard for Wood Circular Saw Blade for cordless saws and dry-cutters maximises battery runtime

The Standard for Wood Circular Saw Blade maximises the cordless saw's battery runtime. Its extra-thin kerf reduces friction and material removal, consuming less power for effortless sawing. High-quality carbide teeth support reliable results. Aggressive tooth angles enable a smooth cutting performance. It is suitable for cutting in all kinds of wood and wooden materials. The blade fits all common cordless plunge and handheld saws as well as cordless dry-cutters.

The Standard for Wood Circular Saw Blade enables reliable cutting results thanks to its high-quality carbide teeth. Expansion slots notably reduce noise and heat while working.