

makita
DUR368AZX3
Akku-
Freischneider
18,0 V, ohne
Akku
(DUR368AZX3)



Model: DUR368AZX3

Manufacturer: MAKITA

EAN: 088381772648

Product Code: 1576406

R9,064

makita DUR368AZX3 Akku-Freischneider 18,0 V, ohne Akku (DUR368AZX3)