

**Bosch 2 607 011
172 jigsaw/scroll
saw/reciprocating
saw blade
Jigsaw blade 10
pc(s)**



Model: 2607011172

Manufacturer: BOSCH

EAN: 3165140913430

Product Code: 1589469

R1,118

The Clean Precision Jigsaw Blade Set, 10-Pieces is the ideal choice for precise and clean results in wood. It contains blades for fine, precise straight and curve cuts in softwood, hardwood and laminate. All blades are compatible with jigsaws with a single lug shank system.