



Bosch AdvancedGrassCut 36 Cordless Grass Trimmer Baretool

Model: 0600878N04

Manufacturer: BOSCH

EAN: 3165140887779

Product Code: 1628873

R2,957

Tame overgrown areas and untouched lawns with powerful cordless trimming

Gain control over overgrowth and untouched lawns with the powerful AdvancedGrassCut 36 cordless grass trimmer and experience outstanding performance with comfort and easy handling. Enjoy efficient, high-quality cutting with the trimmer's dual-line cutting system. Its semi-auto spool ensures uninterrupted, worry-free trimming. The trimmer's one-click rotatable head makes trimming, edging, and finishing easy. Adjust the angle of its secondary handle to reach difficult overgrowth. Eliminate wrestling and work safely around plants with the plant protector for precise and gentle trimming.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.

itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950

Uninterrupted cutting progress

The semi-auto spool feeds the line at every trigger release, eliminating the need to manually adjust the spool or bumping the head. This ensures an optimal cutting line length for uninterrupted and worry-free trimming.

Switch to edging with a tap and twist

The easy edging function enables quick changes from trimming to edging. Simply press the button on the trimmer and twist to turn the tool to edging.