

**Bosch 2 608 900
546 jigsaw/scroll
saw/reciprocating
saw blade
Jigsaw blade
Bimetal 100
pc(s)**



Model: 2608900546

Manufacturer: BOSCH

EAN: 4059952537702

Product Code: 1640354

R3,976

Ensuring the 'clean side' of a jigsaw cut is on the visible part of the work material has always been an art among joiners and woodworkers. Sometimes you can turn the workpiece over, other times the jigsaw itself can be held upside down. Or you could use the EXPERT 'Hardwood 2-side clean', that offers a perfect tear-free cut on both sides thanks to its counter-directed teeth.