

ESGE 5050 manual food chopper Transparent

Model: 5050

Manufacturer: ESGE

EAN: 4011689505003

Product Code: 1685715

R1,217

Do you need finely ground hazelnuts for the nut cake? Do you need finely chopped juniper berries and mustard seeds for the spicy game marinade? Do you need finely ground chocolate as a topping for the dessert? Do you need to process the delicious Parmesan cheese into fine flour for the spaghetti carbonara? Well, the ESGE chopper is responsible for these kitchen questions! The ESGE chopper

is compatible with all ESGE magic wands® except models with 350 watts of power (Gastro and Maître) and transforms food into sprinkleable ingredients in no time at all. Simply fill in the food to be chopped, put the lid on and put on the ESGE magic wand®. Start the magic wand and finely ground food is available in no time! Because the container is transparent, you can always see the grinding level and stop when the desired consistency is achieved.

The two-bladed stainless steel blade chops everything up in no time at all and the rubber ring underneath the container gives the chopper a secure footing, so nothing slips even at high speeds.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950

After use, the blade can be easily removed for cleaning - it couldn't be more convenient!

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.

itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950