

ASUS RP-BE58 Dual-band (2.4 GHz / 5 GHz) Wi-Fi 7 (802.11be) White 1 Internal

Model: RP-BE58

Manufacturer: ASUS

EAN: 4711387709351

Product Code: 407314

R2,441

WiFi Dead Zone Eliminator

BE3600 WiFi 7 Range Extender

Extend WiFi Across Your Home

Enjoy unrivaled wireless performance across your home with a RP-BE58 dual-band range extender, which extends wireless coverage of up to 2,200 sq. ft. Get WiFi where you couldn’t before!

Faster, Smarter Home WiFi 7

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950

The ASUS RP-BE58 boasts cutting-edge WiFi 7 technology. Enjoy next-generation speeds and connected experiences for home entertainment and cloud computing, including 8K streaming, HDR gaming, content creation, and AI network.

Whole-home AiMesh WiFi System

ASUS AiMesh technology lets you easily use the RP-BE58 with another AiMesh-compatible router to expand the coverage of your WiFi network. You can also apply complete features of those connected ASUS routers to the overall mesh network.

Works with Nearly Any WiFi Router

In addition to ASUS AiMesh-compatible devices, the RP-BE58 can work with a wide variety of other WiFi routers, modems, and gateways. Connect the RP-BE58 to your current router to enjoy an expanded WiFi network!
*The WPS button setup and ASUS Extender app setup is not applicable when RP-BE58 is working with AiMesh routers.

Easy and Quick Setup

When Connect to AiMesh Router

Set up your AiMesh wireless network in just three steps with the easy-to-use ASUS Router mobile app*.
*AiMesh-compatible device is required.

When Connect to Non-ASUS/Non-AiMesh Router

In just a few taps, the ASUS Extender mobile app lets you sync and set up the RP-BE58 with your other routers. You can also use the WPS button for one-touch instant connections.*
*The WPS button setup and ASUS Extender app setup are not available when RP-BE58 is in AiMesh mode.

Flexible Backhaul Connection

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950

When RP-BE58 works as an AiMesh node or in Access Point (AP) mode, you can simply connect it to your router with an Ethernet cable. This backhaul reserves the entire 2.4 GHz and 5 GHz band to your wireless devices to create more stable and reliable connections.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950