



Bosch EasyMower 18V- 32-200 Push lawn mower Battery

Model: 06008B9D01

Manufacturer: BOSCH

EAN: 4059952616148

Product Code: 451432

R5,095
