

Bosch
EasySander 18V-
8 06033E3002
Cordless Multi-
sander Incl.
Battery Charger
18



Model: 06033E3002

Manufacturer: BOSCH

EAN: 4053423245653

Product Code: 451636

R3,327