

Ryobi One+
R18DD3-0
Drill/driver
without Battery
No Battery
Cordless Chuck



Model: 5133002889

Manufacturer: RYOBI

EAN: 4892210149152

Product Code: 469115

R2,018