



Duracell Digital Camera Battery Charger



Model: DRN5920

Manufacturer: DURACELL

EAN: 5055190185957

Product Code: 493945

R1,096

This Duracell USB Camera Battery Charger is designed specifically for the Nikon EN-EL14 battery*. The charger is extremely compact, light and convenient and connects to a USB socket for convenient charging anywhere in the world. |*Please note - Battery not included. Available separately.