

Duracell Digital Camera Battery Charger

Model: DRN5926

Manufacturer: DURACELL

EAN: 5055190186015

Product Code: 493949

R1,096

This Duracell USB Camera Battery charger is designed specifically for the Nikon EN-EL19 battery*. The charger is extremely compact, light and convenient and connects to a USB socket for convenient charging anywhere in the world.|*Please note - Battery not included. Available separately.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950