



Duracell Digital Camera Battery Charger



Model: DRN5926

Manufacturer: DURACELL

EAN: 5055190186015

Product Code: 493949

R1,096

This Duracell USB Camera Battery charger is designed specifically for the Nikon EN-EL19 battery*. The charger is extremely compact, light and convenient and connects to a USB socket for convenient charging anywhere in the world. |*Please note - Battery not included. Available separately.