

Ryobi ONE+ 18V R18SDS-0 - bez akumulatora i adowarki



Model: 5133002305

Manufacturer: RYOBI

EAN: 4892210130211

Product Code: 756138

R2,983

Zasilanie: akumulatorowe|Udar: tak | Walizka: tak | Ładowarka: nie