

Ansmann Jump Starter. Powerbank+torch Function



Model: 1900-0130

Manufacturer: ANSMANN

EAN: 4013674172474

Product Code: 823770

R4,011
