

Sony RM-VPR1 Cable Remote Control Multi-terminal

Model: RMVPR1.CE7

Manufacturer: SONY

EAN: 4905524929386

Product Code: 1059426

R2,166

Easily control a camera’s shutter release, video record and zoom

Shoot smooth videos: Start/stop video recording or control zoom from the handy remote without accidentally shaking the camera or camcorder.

Get better macro photographs: Steady, vibration-free shutter release makes all the difference when you need to keep the camera really still for close-up photography.

Stay steady in the dark: The shutter lock function lets you keep the camera shutter open without vibration for beautiful night-time scenes and other long exposures.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950

Keep close control at your fingertips: Easily clip the remote to your camera or camcorder’s tripod for handy operation.

Made for Multi Terminal cameras or camcorders: The remote commander works with NEX, SLT and Cyber-shot™ cameras and Handycam® camcorders with a Multi Terminal*.

Use as a shutter release for A-mount cameras: The remote can be used as a handy shutter release for A-mount cameras without a Multi terminal.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950