Bosch Accessories Jigsaw Guide (2609256981)

Model: 2609256981

Manufacturer: BOSCH

EAN: 3165140572606

Product Code: 1095668

R1,096

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.