Lenovo ThinkPad Power Button Board E14

Model: 5M10W64471

Manufacturer: LENOVO

Product Code: 1268278

R2,018

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.