Bosch 2 608 135 021 power jigsaw accessory

Model: 2608135021

Manufacturer: BOSCH

EAN: 3165140030557

Product Code: 1274981

R4,068

Saw blade guide for saw blade 2 607 018 011.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
itworkup.co.za | sales@itworkup.co.za | +27 (11)541-9950