

Sony LCS-U21 Bag for Digital Camera/camcorder

Model: LCSU21B.SYH

Manufacturer: SONY

EAN: 4905524909074

Product Code: 930526

R2,048

- Keep all your camera or camcorder kit together.
- Quickly open the fastener to film the action.
- Carry comfortably on your shoot or travels.

Easy access with large top lid - Get at everything in your case by opening the large top lid, which also protects the camera or camcorder from rain and sand.
Never miss a shot with quick opening buckle - Access your camera or camcorder quickly without having to close a fastener.
Take all your gear on the shoot - There’s space for a camera or camcorder, spare battery, charger, HDMI cable, shooting accessories and memory card.
Take it anywhere with a tough design - The carrying case offers protection for your camera or camcorder equipment thanks to a durable neoprene material.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.